

Product Manual

Aroma Diffuser



Please read the function introduction based on the product model.

Product Information

Packing List:



Main Unit*1



Bottle*1



Charging Cable*1



Manual*1

Product Parameter:

Name:Aroma Diffuser

Dimension:φ91.3*126mm/φ0.2* 0.4ft

Voltage:5V = 1A

Power:2W

Net Weight:308g/355g

Bottle Capacity:15ml

Coverage :20m²/215ft², 60m³/2118ft³

Lithium Battery: 2000mAh (Only for Model A671)


Grade and Working Period:

Grade	Work Time(s)	Stop Time(s)	Consumption(g/h)	Estimated Days of Use
G1	5	150	0.02	75
G2	10	120	0.06	25
G3	10	60	0.13	11

Note:

- 1.The above data is based on internal company laboratory tests. The data may vary depending on the type of essential oil and environmental conditions. Please refer to actual usage.
- 2.It is recommended to use essential oils with a viscosity not exceeding 30 mPa · s.
- 3.The estimated days of use are calculated based on 15ml essential oil and 10 hours of working per day.

Function Description:



Button Description

Power Button:Long press for 1s to power on/off.

Grade Button:Short press to switch grades(Sequence:G1-G2-G3-G1)

Ambient light button:Short press to switch light color.

Note:Light setting is only effective when powered on.

Indicator Light Description

Grade Indicator Light:

1.When the grade button is switched to a specific level, the corresponding indicator lights will illuminate.

G1●○○ G2●●○ G3●●●

2.-Charging when powered on: Indicator lights scroll 5 times → then display the current grade→ and repeat. (only for Model A671)

-Charging when powered off: Indicator lights scroll continuously. (only for Model A671)

-Fully charged when powered on: Indicator lights display the current grade.(only for Model A671)

-Fully charged when powered off: No indicator lights are shown. (only for Model A671)

Ambient light:

1.11 Light Modes Available: Red,Orange,Yellow,Green,Blue, Indigo, Purple,Pink, White,Cycle,and Off.

2.No lights are shown when powered off.

3.When battery voltage drops below approximately 3.4V±0.15V, the red ambient light will flash as a reminder.(only for Model A671)

Low Battery Warning (Only for Model A671):

Charging Time: Approximately 3.5 to 4 hours for a full charge.

Battery Runtime(at full charge): Red light turns on, set to grade 3, it works for 10s then pauses for 60s ,lasts about 15 hours.

Default Settings

- 1.New device is in powered-off mode by default.
- 2.When powered on, the grade indicator light defaults to grade 1.
- 3.The ambient light defaults to purple when powered on.

How to Add Essential Oil



①Lift upwards to take out the bottle.



②Twist off the bottle, add essential oil and tighten the bottle (Note: When adding essential oil, keep the level below 90% of the bottle' s capacity. Completely filling it up may cause oil to leak.



③Align and place the bottle back into the machine.

Cleaning and Maintenance

When to Clean the Device:Cleaning is required in the following situations:

- 1.When change to a different essential oil.
 - 2.When you notice a decrease in mist output performance.
- Tip: We recommend regular cleaning—about once every 3 months.

Cleaning Steps



①Lift upwards to take out the bottle.



②Pour an appropriate amount of alcohol into the bottle (30%–90% full), install it back onto the machine, and run the device at the highest setting for 15–30 minutes.



③Discard any remaining alcohol and let the diffuser sit until the oil bottle, suction tube, and nozzle are completely dry. Cleaning is now complete.

⚠WARNING

Safety Instructions

To ensure safe use and prevent harm or property damage, please follow these safety precautions. Failure to comply with these warnings may result in accidents. This product is not designed for the following situations:

- Use by unattended infants, individuals with disabilities, or those with cognitive impairments.
- Use as a toy by young children.



Usage and Storage Instructions

- 1.This aroma diffuser is designed for use with essential oils. Please read the manual carefully before use.
- 2.This product is not suitable for individuals with weakened health (including children). Elderly, pregnant individuals, and those with physical, sensory, or intellectual impairments should consult a doctor before use. Those lacking experience or knowledge, especially children, must be supervised by a responsible person to ensure safe use. Otherwise, they should be prevented from accessing the device.
- 3.The optimal operating temperature for the machine is 20-35°C, with a relative humidity of <85%. Diffusion performance may vary depending on environmental temperature and humidity.
- 4.Store essential oils in a cool, dry place with the cap securely closed, away from direct sunlight. The recommended storage temperature is around 25°C.
- 5.Dispose of the product and protective packaging materials in accordance with local regulations.

Prohibited Guidelines

- 1.Keep away from fire sources.
- 2.Do not ingest essential oil; seek medical attention if swallowed.
- 3.Do not use for purposes other than space diffusion; do not apply fragrance essential oil directly to the skin.
- 4.Avoid extreme temperatures (below -5°C or above 40°C).

Mandatory Guidelines

- 1.Keep out of reach of children and pets to prevent accidental ingestion. Supervise children to ensure they do not play with the device.
- 2.Do not modify, disassemble, or repair the machine unless you are a qualified technician. If a malfunction occurs, contact customer service from the original purchase channel.
- 3.Stop using the device immediately if any abnormalities occur during or after use.
- 4.Place the machine on a level surface and keep it upright after installation. Tilting or placing the device flat may cause oil leakage or malfunction.
- 5.Wipe up any spilled essential oil immediately.
- 6.Battery disposal: Wear gloves, place leaking batteries in a plastic bag, and dispose of them properly to avoid environmental contamination.
- 7.The built-in lithium battery must be replaced by qualified technicians.
- 8.Do not use non-rechargeable batteries.

Potential Risks of Injury or Property Damage

- 1.The following actions may cause electric shock, short circuits, or fire hazards:
 - Do not get the machine or charging port wet.
 - Do not use overloaded power outlets, damaged cords, or faulty plugs.
2. When adding essential oil, avoid excessive pressure to prevent leakage and damage to machine components.
3. Do not pull, crush, cut, or tamper with the power cord.
4. To prevent malfunctions or damage, do not disassemble the machine during use.
5. Before disposing of the device, remove the battery. Ensure the device is powered off before removal, and dispose of the battery safely. (Not applicable to non-battery models.)
6. If the adapter, charging cable, or power cord is damaged, it must be replaced with a specialized component provided by the manufacturer or authorized service provider.
7. Use only the specified low-voltage power supply as marked on the device.
8. Only use the power adapter included with the product.
9. Use only the recommended evaporation medium. Using other substances may pose toxic or fire risks.

ISED Statement

English:This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada' s licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.
The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).

French: Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux RSS exemptés de licence d'Innovation, Sciences et Développement économique Canada.
L'exploitation est soumise aux deux conditions suivantes :
(1) Cet appareil ne doit pas provoquer d'interférences.
(2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.
l'appareil numérique du ciem conforme canadien peut-3 (b) / nmb-3 (b).

This device meets the exemption from the routine evaluation limits in section 6.3 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance. cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 6.3 du cnr -102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non contrôlé.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.
SAVE THESE INSTRUCTIONS

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
Not applicable

RF Exposure
This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. be installed and operated with minimum distance 20cm between the radiator & your body.

Troubleshooting

If the aroma diffuser is not functioning properly, please check the following and attempt to resolve the issue.		
Issue	Possible Causes	Solutions
Device not working	The battery has run out of power.	Charge the device in time.
No mist or weak mist	The atomizing core is clogged.	Clean the atomizing core with a professional cleaner to remove internal residue or replace it with a new one. (Recommended cleaning every 3 months.)
	The liquid tube is not securely attached.	Check and tighten the loose parts.
	The gasket between diffuser head and bottle may be loose or damaged.	Secure the bottle properly or replace the gasket if damaged.
Oil leakage	The bottle is not properly secured.	Check and tighten the loose parts.
	The gasket between diffuser head and bottle may be loose or damaged.	Secure the bottle properly or replace the gasket if damaged.
Liquid spray	The atomizing core is clogged.	Clean the atomizing core with a professional cleaner to remove internal residue or replace it with a new one. (Recommended cleaning every 3 months.)
	The device is tilted.	Ensure the device remains upright during use.
Unusual noise	The essential oil level is too high.	Do not overfill the bottle—keep the essential oil level below 90% capacity.
	The air pump is not secured.	Inspect and re-secure the pump if loose.
	The essential oil level is too high.	Do not overfill the bottle—keep the essential oil level below 90% capacity.